


RH-25 Interface Description




RH-25 Packaging Information




List:


- A. Power Supply Cable *2
- B. CAN BUS Communication Cable *4
- C. 120Ω Terminal Resistance *1
- D. EtherCAT Communication Cable *2
- E. CAN BUS Communication Module *1 (For each order, there will be a free USB-CAN adapter. If need more, please contact sales to buy.)


RH-25 Accessories Marking Instructions

A 	Power Supply Cable	
	① XT30(2+2) Connector	
	② Red Line	VCC Positive Power Supply
	③ Black Line	GND Negative Power Supply

B 	CAN BUS Communication Cable	
	① GH1.25-2P Connector	
	② Black Line	CAN_L Network Information Terminal / Negative Power Supply
	③ White Line	CAN_L Network Information Terminal / Positive Power Supply

C 	120Ω Terminal Resistance	
--	---------------------------------	--

D 	EtherCAT Communication Cable	
	① SH1.0mm(4pin) Connector	
	② T	EtherCAT Transmission Wire
	③ R	EtherCAT Receiving Wire

E 	CAN BUS Communication Module	
	① CAN1 Communication Channel	
	② CAN0 Communication Channel	
	③ CANL CANH	
	④ CANL CANH	
	⑤ CAN1 CAN0 120Ω Resistance Switch	

Notes : For each order, there will be a free USB-CAN adapter. If need more, please contact sales to buy.