


RH-17 Lite Interface Description

	Port Definition	Port Description
	① GND	Negative Power Supply
	② VCC	Positive Power Supply
	③ CAN_H	CAN_H Network Information Terminal
	④ GND	Negative Power Supply
	⑤ CAN_L	CAN_L Network Information Terminal



RH-17 Lite Packaging Information



List:

- A. Power Supply Cable *2
- B. CAN BUS Communication Cable *2
- C. 120Ω Terminal Resistance *1
- D. CAN BUS Communication Module *1 (For each order, there will be a free USB-CAN adapter. If need more, please contact sales to buy.)

RH-17 Lite Accessories Marking Instructions

A 	Power Supply Cable	
	① XT30(2+2) Connector	
	② Red Line	VCC Positive Power Supply
B 	CAN BUS Communication Cable	
	① GH1.25-3P Connector	
	② White Line	CAN_L Network Information Terminal
	③ Black Line	GND Negative Power Supply
C 	120Ω Terminal Resistance	
D 	CAN BUS Communication Module	
	① CAN-L	CAN_L Network Information Terminal
	② CAN-H	CAN_H Network Information Terminal
	③ CAN-G	GND Ground
	④ OFF	120Ω Terminal Resistance
	⑤ ON	120Ω Terminal Resistance
Notes : For each order, there will be a free USB-CAN adapter. If need more, please contact sales to buy.		